

BUTTON

KAYIT

TO DELETE, "AKBIL" IS
READ WHILE PRESSING
THE "SIL" BUTTON AND
THE AKBIL IS DELETED
FROM THE DEVICE.